We are often asked; "Can I fit a PVC fitting onto a Hypalon boat or a Hypalon fitting onto a PVC boat?"

Yes, you can, but you do have to follow some basic instructions to ensure a good bond is achieved:

PVC adhesive and Hypalon fabric (and vice versa) are not compatible but a successful bond can be achieved by:

For PVC fittings being fitted to a Hypalon Boat:

- Clean and prime the face of the PVC fitting with MEK Solvent and allow to dry.
 Apply a "primer" coat of 1-part PVC adhesive to the glued face
 Allow to dry

- 4. Glue on using a 2-Part Hypalon Glue, following the instructions on the label

For Hypalon fittings being fitted to a PVC Boat:

- 1. Thoroughly abrade the face of the Hypalon fitting
- 2. Clean using Hypalon Cleaning Solvent
- 3. Apply a "primer" coat of 1-part Hypalon adhesive to the glued face
- 4. Allow to dry
- 5. Glue on using a 2-Part PVC Glue, flowing the instructions on the label