

## Owner's Manual & Safety Instructions

**Save This Manual** Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

# BATTERY OPERATED LIQUID TRANSFER PUMP



# seago®

Equip for Adventure

### ▲WARNING

Read this material before using this product.  
Failure to do so can result in serious injury.  
SAVE THIS MANUAL.

**seago®**  
Equip for Adventure

[www.seagoyachting.co.uk](http://www.seagoyachting.co.uk)

## WARNING SYMBOLS AND DEFINITIONS

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
	Addresses practices not related to personal injury.

## Specifications

Battery Requirement	Two D-Cell (not included)
Delivery Hose Length	24"
Suction Hose	13" L x 1" Diameter
Flow Rate	Approximately 5 Litres/Min
Compatible Fluids	Petrol, Water, Oil, other Non-Corrosive Liquids

## IMPORTANT SAFETY INFORMATION

**WARNING** Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in serious injury. Save all warnings and instructions for future reference.

- Do not use with corrosive liquids. Not for use with drinking water.
- When pumping petrol and flammable liquids, be alert to possible explosion hazard. Flammable fluid fumes and petrol vapors can be an explosive hazard. Avoid sparks and use only with adequate ventilation.
- Wear safety goggles and heavy-duty chemical resistant work gloves during use.
- This product is not a toy. Do not allow children to play with or near this item.
- Use as intended only. Only use pump for transferring petrol, water, oil, and other non-corrosive liquids.
- Do not use if Pump is hot.
- Verify that all connections are tight before use to eliminate leaking.
- Do not pump used, dirty oil.
- Do not use near open flame or heat sources.
- Do not turn Pump upside down after use.
- Remove batteries when not in use.
- Dispose of waste properly in accordance with all local laws and regulations.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Position batteries in proper polarity. Do not use swollen or leaking batteries.
- Do not operate when tired or when under the influence of drugs or medication.
- Inspect before every use; do not use if parts are loose or damaged.
- Maintain product labels and nameplates. These carry important safety information.



**SAVE THESE INSTRUCTIONS.**

## Operating Instructions



Read the **ENTIRE WARNING** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

## Battery Installation

- Unscrew Battery Cap counterclockwise and remove.
- Insert two D-Cell batteries (not included) into the Battery Housing. Be sure to install batteries in proper polarity. Do not install batteries of different types, charge levels, or capacities together.
- Replace the Battery Cap and tighten securely.




Figure A

## Operation

- Insert the Suction Tube as far as possible into the liquid to be transferred.
  - Place the Delivery Hose into a container (not included) in which to pump the liquid. Do not place receiving container higher than the Battery Housing.
  - Turn the ON/OFF Switch to ON. Make sure the battery compartment remains sealed during operation.
- NOTICE:** Do not run unit dry. Make sure Suction Tube is fully submerged in liquid before turning on.
- When the transfer is complete, turn the Switch OFF. After use, do not turn Pump upside down.
  - Rinse unit with water and wipe dry. Remove batteries and store in a clean, dry location out of reach of children.

## Maintenance



Procedures not specifically explained in this manual must be performed only by a qualified technician.

## WARNING

**TO PREVENT SERIOUS INJURY FROM TOOL FAILURE: Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.**

- BEFORE EACH USE**, inspect the general condition of the Liquid Transfer Pump. Check for:
  - loose hardware
  - misalignment or binding of moving parts
  - cracked or broken parts
  - any other condition that may affect its safe operation.
- AFTER USE**, rinse Pump with water. Wipe unit dry after cleaning.
- Remove batteries. Store the Liquid Transfer Pump in a clean, dry location out of reach of children.